

# Pottery Oven



## Instruction Mandatory

Instruction **prior** to use is **mandatory**. Check the wiki for who can help you.

This oven is for pottery, ceramics, annealing and similar use. Up to 1200°C.

Please write down the electricity use (kWh counter) and pay €0.25/kWh to the foundation (NL30 TRIO 0197 6945 19).



## No mid-bake opening

This oven is not designed to be opened while hot. Or to have contents removed (or added) while hot.



## Bare electric wires inside

Do not open the oven while powered on. The heating spirals are not isolated.



## No fumes

This oven has no exhaust. So no metal melting or similar.



## Stay with the machine

Stay with the machine during the first hour or so



## No Lookie

The openings (e.g. at the top) are not for looking through. They are for exhaust and temperature measurements. The hot air of 800°C-1200°C will damage your eye.



## Be present when the heating is supposed to finish

You **MUST** be at the machine when it is near finished heating or check within one or two hours thereafter.

Stay with the machine during the first few hours. Be present when it is supposed to finish (or soon thereafter) – as the machine lacks an extra safety mechanism and may not shut down properly. If a machine is not clean or appears broken - then report this to the mailing list. Clean/fix prior to use.

**Report any damage, issues or accident within 24 hours to the mailing list.**