Jung Surface Grinder



Instructions & Approval Mandatory

Instruction **prior** to use is **mandatory**. Check the wiki for who can help you. You must also have a '**dangerous equipment waiver**' filed with the foundations trustees and been given **approval or card access** to use the machine.

Be very gentle with the Z-axis; do not plunge or ram it into the surface.

If you notice any imbalance - stop immediately. Disk or machine can quickly destroy themselves.



Aluminium Forbidden

It is forbidden to grind Aluminium. Just don't (it forms termite when it combines with oxidised steel particles



Eye protection mandatory

Sparks will fly, the grinding disk can shatter



Wear protective clothing

Wear tight fitting clothing, keep long hair out tied up, no jewellery or anything else that can be caught by the machine.



Do not wear gloves

Especially strong leather ones. They get caught easily and then 'help' ripping body parts off.



Crushing

Risk of crushing – the machine does not have any sensors that detect obstacles.



Grinding wheel runs invisibly

The grinding wheel will run very smooth, barely visible - and will continue to be dangerous for a minute or so after shutoff



Slippery surface

Floor will get very slippery; especially when using coolant.



Wear a mask when needed

And be very careful with truly nasty material. Grinding carbide is not allowed.

If a machine is not clean or appears broken - then report this to the mailing list. Clean/fix prior to use.

Report any damage, issues or accident within 24 hours to the mailing list.