

Wood Router



Instruction Mandatory

Instruction **prior** to use is **mandatory**. Check the wiki for who can help you.

This machine is for WOOD only.



Wear protective clothing

Wear tight fitting clothing, keep long hair out tied up, no jewellery or anything else that can be caught by the machine.



Wear a mask when needed

Especially when cutting materials such as MDF



Eye protection recommended



Sharp rotating elements

Bypassing or using your fingers to hold the guard open is downright stupid.



Ear protection recommended

Note also that this machine should not be used after 19:00 if it is so noisy that you need ear protection.

If a machine is not clean or appears broken - then report this to the mailing list. Clean/fix prior to use.

Report any damage, issues or accident within 24 hours to the mailing list.